



Prop the cradle on blocks to allow clearance for the saw to cut.



Saw both sides nearly thru to bottom.



With both sides nearly sawed thru, the swing assemblies mounted on the jig will begin to fall and the frame will start to separate.



Both sides should be dropping equally, coming to rest back on the cradle jig. Complete cutting entirely thru the metal on both sides.



With both pieces sawed, center the pieces and move them so there is a 10 1/2" gap back from where they were cut off.



Check 3 or 4 times to make sure both sides are 10 1/2" separation.